


TriPlus Position Keyboard Commands

These manual commands allow the mechanical fine alignment of the of the syringe carriage assembly on the GC injector. They are carried out by using the keyboard of the PC.



The syringe carrier assembly is step-by-step moved on left/right, up/down, forth/back, by using the relevant key.

- Use the lowercase letter for a fine movement
- Use the uppercase letter for a wider movement

